FIRTREE® LAS1016 PERIMETER SEAL

FITTING GUIDE



LENGTH	

CONTENTS

• FIRTREE® LAS1016 perimeter seal

TOOLS REQUIRED

- Tape measure
- Pencil or marker
- Router with 3mm cutter (Firtree® only)
- · Scissors, knife or snips

INSTALLATION DETAIL

STEP 1

Remove the seal from the packaging and measure the door height to determine the seal length required. Cut lengths to suit door frame.

STEP 2

Groove the door or frame 3mm wide x 4mm deep.

STEP 3

Push fit the LAS1016 product into the groove.

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.



DISCLAIMER

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers. Lorient reserves the right to make alterations or delete installation detail without prior notice.



ASSA ABLOY LTD T/A LORIENT
Endeavour House
Fairfax Road
Heathfield Ind Estate
Newton Abbot
Devon TQ12 6UD
United Kingdom

+44 (0)1626 834252 www.lorient.com.au

All rights reserved. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient.

© 2024 ASSA ABLOY Ltd T/A Lorient. Lorient is a registered trade mark of ASSA ABLOY LIMITED in England.



Gasketing materials for fire doors intended for application to wood and plastic covered composite and wood core doors rated up to 1.5 hours. Listed steel frames and/or classified steel covered composite, hollow metal doors rated up to 3 hours.

For more information please call: